


**Wide Operating  
Temperature**



# **IEC-3900**

**Digital Signage Player with 7th Generation  
Intel® Core™ i7/ i5 processor**

## **User's Manual**

**Version 1.1**

---

## Revision History

Version	Date	Description
1.0	2019.08	Initial release
1.1	2020.02	• <a href="#">1.6. Optional Accessories &amp; CTOS</a> Add COM port cable & bracket

<b>Revision History .....</b>	<b>ii</b>
<b>Contents .....</b>	<b>i</b>
<b>Preface.....</b>	<b>iii</b>
Copyright Notice .....	iii
Declaration of Conformity .....	iii
CE.....	iii
FCC Class A .....	iv
RoHS .....	iv
SVHC / REACH .....	v
Important Safety Instructions .....	v
Warning.....	vi
Lithium Battery Replacement.....	vi
Technical Support .....	vii
Warranty.....	vii
<b>Chapter 1 - Introduction.....</b>	<b>1</b>
1.1. Features.....	2
1.2. About this Manual .....	2
1.3. Specifications.....	3
1.4. Inside the Package .....	4
1.5. Ordering Information .....	4
1.6. Optional Accessories & CTOS .....	5
<b>Chapter 2 - Getting Started.....</b>	<b>7</b>
2.1. Dimensions .....	8
2.2. Tour the Computer .....	9
2.3. Driver (6.8A) Installation Note.....	9
<b>Chapter 3 - Engine of the Computer.....</b>	<b>11</b>
3.1. Board Layout.....	12
3.1.1. Carrier Board .....	12
3.1.2. COM Express Compact Type 6 CPU Module.....	13
3.2. Connectors Quick Reference.....	14
3.2.1. Connectors .....	15
3.2.2. COM Express Connectors .....	20
<b>Chapter 4 - Installation and Maintenance.....</b>	<b>23</b>
4.1. Access the Inside of the Computer .....	24
4.2. Installing M.2 SSD .....	26
4.3. Installing Memory Module .....	27
4.4. Replacing RTC Battery .....	28
4.5. Wall Mount the Computer .....	30
<b>Chapter 5 - BIOS.....</b>	<b>33</b>

- 5.1. Main ..... 34
- 5.2. Advanced ..... 36
  - 5.2.1. CPU Configuration ..... 37
  - 5.2.2. ACPI Settings ..... 38
  - 5.2.3. USB Configuration ..... 39
  - 5.2.4. Hardware Monitor ..... 41
  - 5.2.5. S5 RTC Wake Settings ..... 42
  - 5.2.6. CSM Configuration ..... 43
  - 5.2.7. NVMe Configuration ..... 44
- 5.3. Chipset ..... 45
  - 5.3.1. Graphics Configuration ..... 46
  - 5.3.2. SATA and RST Configuration ..... 46
- 5.4. Security ..... 47
- 5.5. Boot ..... 48
- 5.6. Save & Exit ..... 49

## Copyright Notice

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve the reliability, design and function. It does not represent a commitment on the part of the manufacturer.

Under no circumstances will the manufacturer be liable for any direct, indirect, special, incidental, or consequential damages arising from the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## Declaration of Conformity

### CE

The CE symbol on your product indicates that it is in compliance with the directives of the Union European (EU). A Certificate of Compliance is available by contacting Technical Support.

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from ARBOR. Please contact your local supplier for ordering information.

### Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## **FCC Class A**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

### **NOTE:**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## **RoHS**

ARBOR Technology Corp. certifies that all components in its products are in compliance and conform to the European Union's Restriction of Use of Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive 2002/95/EC.

The above mentioned directive was published on 2/13/2003. The main purpose of the directive is to prohibit the use of lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE) in electrical and electronic products. Member states of the EU are to enforce by 7/1/2006.

ARBOR Technology Corp. hereby states that the listed products do not contain unintentional additions of lead, mercury, hex chrome, PBB or PBDB that exceed a maximum concentration value of 0.1% by weight or for cadmium exceed 0.01% by weight, per homogenous material. Homogenous material is defined as a substance or mixture of substances with uniform composition (such as solders, resins, plating, etc.). Lead-free solder is used for all terminations (Sn(96-96.5%), Ag(3.0-3.5%) and Cu(0.5%)).

## **SVHC / REACH**

To minimize the environmental impact and take more responsibility to the earth we live, Arbor hereby confirms all products comply with the restriction of SVHC (Substances of Very High Concern) in (EC) 1907/2006 (REACH --Registration, Evaluation, Authorization, and Restriction of Chemicals) regulated by the European Union.

All substances listed in SVHC < 0.1 % by weight (1000 ppm)

## **Important Safety Instructions**

Read these safety instructions carefully

1. Read all cautions and warnings on the equipment.
2. Place this equipment on a reliable surface when installing. Dropping it or letting it fall may cause damage
3. Make sure the correct voltage is connected to the equipment.
4. For pluggable equipment, the socket outlet should be near the equipment and should be easily accessible.
5. Keep this equipment away from humidity.
6. The openings on the enclosure are for air convection and protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
7. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
8. Never pour any liquid into opening. This may cause fire or electrical shock.
9. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
10. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped or damaged.

- f. The equipment has obvious signs of breakage.
11. Keep this User's Manual for later reference.



**Caution:** This equipment is not suitable for use in locations where children are likely to be present.



**Hot Parts!**

Burned fingers when handling the parts.  
Wait one-half hour after switching off before handling parts.

## Warning

The equipment and its components contain very delicately Integrated Circuits (IC). To protect the equipment and its components against damage caused by static electricity, you should always follow the precautions below when handling it:

1. Disconnect the equipment from the power source when you want to work on the inside.
2. Use a grounded wrist strap when handling equipment components.
3. Place components on a grounded antistatic pad or on the bag that came with the Box PC, whenever components are separated from the system.
4. The equipment must be earthed. The power plug must be connected to a properly wired earth ground socket outlet. An improperly wired socket outlet could place hazardous voltages on accessible metal parts.

## Lithium Battery Replacement

Incorrect replacement of the lithium battery may lead to a risk of explosion.

The lithium battery must be replaced with an identical battery or a battery type recommended by the manufacturer.

Do not throw lithium batteries into the trash can. It must be disposed of in accordance with local regulations concerning special waste.



## Technical Support

If you have any technical difficulties, please consult the user's manual first at:  
<http://www.arbor.com.tw>

Please do not hesitate to call or e-mail our customer service when you still cannot find out the answer.

<http://www.arbor-technology.com>

E-mail: [info@arbor.com.tw](mailto:info@arbor.com.tw)

## Warranty

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster.

Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Vendor will not be liable for any claim made by any other related party.

Vendors disclaim all other warranties, either expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the hardware, the accompanying product's manual(s) and written materials, and any accompanying hardware. This limited warranty gives you specific legal rights.

Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

---

This page is intentionally left blank.

---

# Chapter 1

## Introduction

## 1.1. Features

- 7th Gen. Intel® Core™ i7/ i5 processor installed
- Support 2 x HDMI 2.0 with independent video outputs
- Support 1 x COM, 4 x USB3.0, 1 x GbE port
- Support Intel® vPro & AMT
- Wide range operating temperature: -20 ~70°C



## 1.2. About this Manual

This manual is meant for the experienced users and integrators with hardware knowledge of personal computers. If you are not sure about the description in this manual, consult your vendor before further handling.

We recommend that you keep one copy of this manual for the quick reference for any necessary maintenance in the future. Thank you for choosing ARBOR products.

### 1.3. Specifications

System	
<b>CPU</b>	Soldered onboard 7 <sup>th</sup> Gen. Intel® Core™ i7-7600U 2.8GHz (base)/ 3.9GHz (Turbo); i5-7300U 2.6GHz (base)/ 3.5GHz (Turbo); Processor
<b>Memory</b>	Two DDR4 SO-DIMM sockets, supporting up to 16GB memory
<b>Graphics</b>	Integrated Intel HD Graphics 620
<b>Storage</b>	M.2 m-key 2280 socket, supporting SATA SSD upgradable to 128GB
<b>LAN Chipset</b>	1 x Intel® i219LM PCIe GbE PHY, support vPro & AMT
<b>Watchdog Timer</b>	1~255 levels reset
I/O	
<b>Serial Port</b>	1 x RS-232 port with RJ-45 connector
<b>USB Port</b>	4 x USB 3.0 ports
<b>LAN</b>	1 x RJ-45 ports for GbE
<b>Video Port</b>	2 x HDMI 2.0 video outputs, support 4K/60Hz on both HDMI ports simultaneously
Environmental	
<b>Operating Temp.</b>	-20 ~ 70°C (-4 ~ 158°F), ambient w/ air flow
<b>Storage Temp.</b>	-40 ~ 85°C (-40 ~ 185°F)
<b>Operating Humidity</b>	10 ~ 95% @ 70°C (non-condensing)
<b>Vibration</b>	1.0 Grms, IEC 60068-2-64, random, 5 ~500 Hz, 1 Oct./min, 1 hr/axis, operation
<b>Shock</b>	Operating 10G (11ms), non-operating 20G
Qualification	
<b>Certification</b>	CE, FCC Class A
Power Requirement	
<b>Power Input</b>	DC 24V/2A input (16V~28V)
<b>Power Consumption</b>	Max. 60W (90W for Wide Temperature)
Mechanical	
<b>Construction</b>	Aluminum alloy

<b>Mounting</b>	Wall-mount
<b>Weight</b>	0.73 Kg (1.61 lb)
<b>Dimensions (W x D x H)</b>	130 x 124 x 35 mm (5.12" x 4.88" x 1.37")
<b>OS Support</b>	
Windows 10 IoT / Linux	

### 1.4. Inside the Package

Upon opening the package, carefully inspect the contents. If any of the items is missing or appears damaged, contact your local dealer or distributor. The package should contain the following items:



1 x IEC-3900



1 x **Accessory Box** that contains the following items:

- User's manual
- Screws
- 60W power adapter (90W for Wide Temperature) / EU & US power cords

### 1.5. Ordering Information

<b>IEC-3900-7600U</b>	Digital Signage Player with Intel® Core™ i7-7600U, w/ 2xHDMI, power adapter
<b>IEC-3900-7300U</b>	Digital Signage Player with Intel® Core™ i5-7300U, w/ 2xHDMI, power adapter

---

## 1.6. Optional Accessories & CTOS

---

### Optional Configuration (CTOS\* Kit)

---

SSD                      64GB M.2 SSD

---



SSD                      128GB M.2 SSD

---

DDR4 4GB              260-pin DDR4-2133 4GB SO-DIMM

---



DDR4 8GB              260-pin DDR4-2133 8GB SO-DIMM

---

COM port cable      RJ-45 to DB-9 male cable

---



Bracket                IEC-3900 series bracket

---



---

This page is intentionally left blank.




---

# Chapter 2

## Getting Started


## 2.1. Dimensions



Unit: mm

## 2.2. Tour the Computer

Take a look around the computer and find the external controls and connectors.



## 2.3. Driver (6.8A) Installation Note

The computer supports Windows 10 IoT. To install the drivers, please go to our website at [www.arbor-technology.com](http://www.arbor-technology.com) and download the driver pack from the product page.

Windows 10 64-bit	
Chipset	\EmETXe-i90x0\Chipset
Graphic	\EmETXe-i90x0\Graphic\win64
Audio	\EmETXe-i90x0\Audio\Win1- _Win8.1 _Win8 _Win7 _WHQLx64
Ethernet	\EmETXe-i90x0\Ethernet
RST	\EmETXe-i90x0\RST\SetupRST
ME	\EmETXe-i90x0\ME

---

This page is intentionally left blank.

---


# Chapter 3

## Engine of the Computer


### 3.1. Board Layout

#### 3.1.1. Carrier Board



##### Board Top



##### Board Bottom



### 3.1.2. COM Express Compact Type 6 CPU Module



## 3.2. Connectors Quick Reference

### Connectors


Label	Description
① DCIN1	DC jack
② COM1	RS-232 Serial Port
③ ④ HDMI2, 1	HDMI Vertical Connector
⑤ ⑥ USB1, 2	Stacked USB 3.0/2.0 Connector
⑦ LAN1	RJ-45 GbE Connector
⑧ FAN1	CPU Fan Power Connector
⑨ JFRT1	Front-panel Connector
⑩ LPC1	Low Pin Count Connector
⑪ AB Connector	COM Express AB Connector (on carrier board)
⑫ CD Connector	COM Express CD Connector (on carrier board)
⑬ SSD1	M.2 M-key Socket
⑭ BAT1	RTC Battery Connector
⑮ SYSLED1	Power LED & System Power On/Off button
⑯ AB Connector	COM Express AB Connector (on CPU module)
⑰ CD Connector	COM Express CD Connector (on CPU module)




### 3.2.1. Connectors

#### ① DCIN1

**Function:** 24V Adapter in DC jack  
**Connector Type:** 2.5φ DC jack with nut and washer



Pin	Description
Center	24V
Inner circle	GND





#### ② COM1

**Function:** RS-232 Serial Port

**Pin Assignment:**

**Connector Type:** RS-232 port with RJ-45 connector

Pin	Desc.
1	DSR#
2	DCD#
3	DTR#
4	GND
5	RXD
6	TXD
7	CTS#
8	RTS#




③④ **HDMI2, 1**

**Function:** HDMI Vertical Connector

**Connector Type:** 19-pin HDMI connector

**Pin Assignment:**

The pin assignments conform to the industry standard.





⑤⑥ **USB1, 2**

**Function:** Stacked USB 3.0/2.0 Connector

**Connector Type:** Double-stacked USB 3.0/2.0 type-A connector

**Pin Assignment:**

The pin assignments conform to the industry standard.




## ⑦ LAN1

**Function:** RJ-45 GbE Connector  
**Connector Type:** 10/100/1000Mbps fast Ethernet RJ-45 connector

### Pin Assignment:

The pin assignments conform to the industry standard.




## ⑧ FAN1

**Function:** CPU Fan Power Connector  
**Connector Type:** 2.54mm pitch 1x3-pin one-wall connector

### Pin Assignment:

#### Pin Description

- |   |           |
|---|-----------|
| 1 | GND       |
| 2 | +VFANS    |
| 3 | CPU_TACCH |




⑨ JFRT1

**Function:** Front-panel Connector

**Connector Type:** 2.00mm pitch 2x5-pin wafer header

**Pin Assignment:**

Pin	Desc.	Pin	Desc.
2	HDDLED+	1	PWLED+
4	HDDLED-	3	PWLED-
6	RESET-	5	PWRBT_IN+
8	RESET+	7	PWRBT_IN-
10	Speaker+	9	Speaker-




⑩ LPC1

**Function:** Low Pin Count Connector

**Connector Type:** 2.00mm pitch 2x5-pin header

**Pin Assignment:**

Pin	Desc.	Pin	Desc.
1	CLK_PCI_TPM	2	GND
3	LFRAME#	4	LAD0
5	CB_RESET#	6	INT_SERIRQ
7	LAD3	8	LAD2
9	+V3.3S	10	LAD1



⑪ AB Connector

⑫ CD Connector

Refer to [3.2.2. COM Express Connectors](#) on page [20](#).

⑬ SSD1

**Function:** M.2 M-Key Socket

**Connector Type:** M.2 M-key 2280 Socket for SSD

**Pin Assignment:**

The pin assignments conform to the industry standard.



**⑭ BAT1**

**Function:** RTC Battery connector  
**Connector Type:** 2.00 mm pitch 1x2-pin header  
**Setting:**

Pin	Desc.
1	GND
2	3V

**⑮ SYSLED1**

**Function:** Power LED & System Power On/Off button

**⑯ COM Express AB Connector****⑰ COM Express CD Connector**

Refer to [3.2.2. COM Express Connectors](#) on page [20](#).

### 3.2.2. COM Express Connectors

#### AB Connector

B1	GND	GND (FIXED)	A1	B56	PCIE_RXN6	PCIE_TXN6	A56
B2	LAN_LED_ACT#	LAN1_MDI3N	A2	B57	DIO_2	GND	A57
B3	LPC_FRAME#	LAN1_MDI3P	A3	B58	PCIE_RXP4	PCIE_TXP4	A58
B4	LPC_AD0	LAN_LED_100#	A4	B59	PCIE_RXN4	PCIE_TXN4	A59
B5	LPC_AD1	LAN_LED_1000#	A5	B60	GND	GND	A60
B6	LPC_AD2	LAN1_MDI2N	A6	B61	PCIE_RXP3	PCIE_TXP3	A61
B7	LPC_AD3	LAN1_MDI2P	A7	B62	PCIE_RXN3	PCIE_TXN3	A62
B8	LPC_LDRQ0-	LAN_LED_LNK#	A8	B63	DIO_3	DIO_1	A63
B9	LPC_LDRQ1-	LAN1_MDI1N	A9	B64	PCIE_RXP2	PCIE_TXP2	A64
B10	LPC_CLK	LAN1_MDI1P	A10	B65	PCIE_RXN2	PCIE_TXN2	A65
B11	GND	GND (FIXED)	A11	B66	PCH_WAKE#	GND	A66
B12	CB_PWRBTN#	LAN1_MDI0N	A12	B67	EC_WAKE_IN#	DIO_2	A67
B13	SMB_CLK	LAN1_MDI0P	A13	B68	GND	PCIE_TXP1	A68
B14	SMB_DATA	OV9_LAN	A14	B69	PCIE_RXN1	PCIE_TXN1	A69
B15	SMB_ALERT#	SLP_S3#	A15	B70	GND	GND	A70
B16	SATA_TXP1	SATA_TXP0	A16	B71	LVDSB_DATA0	LVDSA_DATA0	A71
B17	SATA_TXN1	SATA_TXN0	A17	B72	LVDSB_DATA0-	LVDSA_DATA0-	A72
B18	SUS_STAT#	SLP_S4#	A18	B73	LVDSB_DATA1	LVDSA_DATA1	A73
B19	SATA_RXP1	SATA_RXP0	A19	B74	LVDSB_DATA1-	LVDSA_DATA1-	A74
B20	SATA_RXN1	SATA_RXN0	A20	B75	LVDSB_DATA2	LVDSA_DATA2	A75
B21	GND	GND (FIXED)	A21	B76	LVDSB_DATA2-	LVDSA_DATA2-	A76
B22	N/C	N/C	A22	B77	LVDSB_DATA3	LVDS_VDD_EN	A77
B23	N/C	N/C	A23	B78	LVDSB_DATA3-	LVDSA_DATA3	A78
B24	CB_PWROK	SLP_S5#	A24	B79	LVDS_BKLT_EN	LVDSA_DATA3-	A79
B25	N/C	N/C	A25	B80	GND	GND	A80
B26	N/C	N/C	A26	B81	LVDSB_CLK+	LVDSA_CLK+	A81
B27	WDT	PM_BATLOW#	A27	B82	LVDSB_CLK-	LVDSA_CLK-	A82
B28	N/C	SATALED	A28	B83	COM_BKLT_CTRL	LVDS_DDC_CLK	A83
B29	HDA_SDIN1	HDA_SYNC	A29	B84	VCC_5V_SBY	LVDS_DDC_DATA	A84
B30	HDA_SDINO	HDA_RST-	A30	B85	VCC_5V_SBY	DIO_3	A85
B31	GND	GND	A31	B86	VCC_5V_SBY	H_RCIN#	A86
B32	SPKR	HDA_BIT_CLK	A32	B87	VCC_5V_SBY	A20GATE	A87
B33	I2C_CLK	HDA_SDOUT	A33	B88	BIOS_DIS1#	COM_EXP_CLK_P	A88
B34	I2C_DAT	BIOS_DIS0#	A34	B89	N/C	COM_EXP_CLK_N	A89
B35	THRM#	CB_TRIP#	A35	B90	GND	GND	A90
B36	USBP_7N	USBP_6N	A36	B91	N/C	+V3.3A	A91
B37	USBP_7P	USBP_6P	A37	B92	N/C	SPI_MISO	A92
B38	USBOC_45-	USBOC_67-	A38	B93	N/C	DIO_0	A93
B39	USBP_5N	USBP_4N	A39	B94	N/C	SPI_CLK	A94
B40	USBP_5P	USBP_4P	A40	B95	N/C	SPI_MOSI	A95
B41	GND	GND	A41	B96	N/C	COM_TMP_PP	A96
B42	USBP_3N	USBP_2N	A42	B97	SPL_CS1#	N/C	A97
B43	USBP_3P	USBP_2P	A43	B98	N/C	UART_TX0	A98
B44	USBOC_01-	USBOC_23-	A44	B99	N/C	UART_RX0	A99
B45	USBP_1N	USBP_0N	A45	B100	GND	GND	A100
B46	USBP_1P	USBP_0P	A46	B101	FAN_PWMOUT	UART_TX1	A101
B47	PLTRST#_BUFF	VCC_RTC	A47	B102	FAN_TACHIN	UART_RX1	A102
B48	EXCD1_CCPE#	PLTRST#_BUFF	A48	B103	SLEEP#	LID#	A103
B49	CB_SYSRST#	EXCD0_CCPE#	A49	B104	VCC_12V	VCC_12V	A104
B50	CB_RESET#	LPC_SERIRQ	A50	B105	VCC_12V	VCC_12V	A105
B51	GND	GND	A51	B106	VCC_12V	VCC_12V	A106
B52	PCIE_RXP7	PCIE_TXP7	A52	B107	VCC_12V	VCC_12V	A107
B53	PCIE_RXN7	PCIE_TXN7	A53	B108	VCC_12V	VCC_12V	A108
B54	DIO_1	DIO_0	A54	B109	VCC_12V	VCC_12V	A109
B55	PCIE_RXP6	PCIE_TXP6	A55	B110	GND	GND	A110

## CD Connector

D1	GND (FIXED)	GND (FIXED)	C1	D56	N/C	N/C	C56
D2	GND	GND	C2	D57	TYPE2#	N/C	C57
D3	USB_SSTX0-	USB_SSRX0-	C3	D58	N/C	N/C	C58
D4	USB_SSTX0+	USB_SSRX0+	C4	D59	N/C	N/C	C59
D5	GND	GND	C5	D60	GND (FIXED)	GND (FIXED)	C60
D6	USB_SSTX1-	USB_SSRX1-	C6	D61	N/C	N/C	C61
D7	USB_SSTX1+	USB_SSRX1+	C7	D62	N/C	N/C	C62
D8	GND	GND	C8	D63	N/C	N/C	C63
D9	USB_SSTX2-	USB_SSRX2-	C9	D64	N/C	N/C	C64
D10	USB_SSTX2+	USB_SSRX2+	C10	D65	N/C	N/C	C65
D11	GND (FIXED)	GND (FIXED)	C11	D66	N/C	N/C	C66
D12	USB_SSTX3-	USB_SSRX3-	C12	D67	N/C	N/C	C67
D13	USB_SSTX3+	USB_SSRX3+	C13	D68	N/C	N/C	C68
D14	GND	GND	C14	D69	N/C	N/C	C69
D15	DDI1_CTRLCLK_AUX+	N/C	C15	D70	GND (FIXED)	GND (FIXED)	C70
D16	DDI1_CTRLCLK_AUX-	N/C	C16	D71	N/C	N/C	C71
D17	N/C	RSVD	C17	D72	N/C	N/C	C72
D18	N/C	RSVD	C18	D73	GND	GND	C73
D19	PCIE_TX6+	PCIE_RX6+	C19	D74	N/C	N/C	C74
D20	PCIE_TX6-	PCIE_RX6-	C20	D75	N/C	N/C	C75
D21	GND(FIXED)	GND(FIXED)	C21	D76	GND	GND	C76
D22	PCIE_TX7+	PCIE_RX7+	C22	D77	N/C	N/C	C77
D23	PCIE_TX7-	PCIE_RX7-	C23	D78	N/C	N/C	C78
D24	N/C	DDI1_HPD	C24	D79	N/C	N/C	C79
D25	N/C	N/C	C25	D80	GND (FIXED)	GND (FIXED)	C80
D26	DDI1_PAIR0+	N/C	C26	D81	N/C	N/C	C81
D27	DDI1_PAIR0-	RSVD	C27	D82	N/C	N/C	C82
D28	N/C	RSVD	C28	D83	N/C	N/C	C83
D29	DDI1_PAIR1+	N/C	C29	D84	GND	GND	C84
D30	DDI1_PAIR1-	N/C	C30	D85	N/C	N/C	C85
D31	GND(FIXED)	GND (FIXED)	C31	D86	N/C	N/C	C86
D32	DDI1_PAIR2+	DDI2_CTRLCLK_AUX+	C32	D87	GND	GND	C87
D33	DDI1_PAIR2-	DDI2_CTRLCLK_AUX-	C33	D88	N/C	N/C	C88
D34	DDI1_DDC_AUX_SEL	DDI2_DDC_AUX_SEL	C34	D89	N/C	N/C	C89
D35	N/C	RSVD	C35	D90	GND (FIXED)	GND (FIXED)	C90
D36	DDI1_PAIR3+	N/C	C36	D91	N/C	N/C	C91
D37	DDI1_PAIR3-	N/C	C37	D92	N/C	N/C	C92
D38	N/C	N/C	C38	D93	GND	GND	C93
D39	DDI2_PAIR0+	N/C	C39	D94	N/C	N/C	C94
D40	DDI2_PAIR0-	N/C	C40	D95	N/C	N/C	C95
D41	GND(FIXED)	GND(FIXED)	C41	D96	GND	GND	C96
D42	DDI2_PAIR1+	N/C	C42	D97	N/C	N/C	C97
D43	DDI2_PAIR1-	N/C	C43	D98	N/C	N/C	C98
D44	DDI2_HPD	N/C	C44	D99	N/C	N/C	C99
D45	N/C	RSVD	C45	D100	GND (FIXED)	GND (FIXED)	C100
D46	DDI2_PAIR2+	N/C	C46	D101	N/C	N/C	C101
D47	DDI2_PAIR2-	N/C	C47	D102	N/C	N/C	C102
D48	N/C	RSVD	C48	D103	GND	GND	C103
D49	DDI2_PAIR3+	N/C	C49	D104	VCC_12V	VCC_12V	C104
D50	DDI2_PAIR3-	N/C	C50	D105	VCC_12V	VCC_12V	C105
D51	GND (FIXED)	GND (FIXED)	C51	D106	VCC_12V	VCC_12V	C106
D52	N/C	N/C	C52	D107	VCC_12V	VCC_12V	C107
D53	N/C	N/C	C53	D108	VCC_12V	VCC_12V	C108
D54	PEG_LANE_RV#	N/C	C54	D109	VCC_12V	VCC_12V	C109
D55	N/C	N/C	C55	D110	GND (FIXED)	GND (FIXED)	C110

---

This page is intentionally left blank.



---


# Chapter 4

## Installation & Maintenance


## 4.1. Access the Inside of the Computer

To use onboard jumpers/connectors or to install/remove internal components, you will need to open the computer to access the inside of the computer. Follow through the guide below to access the inside of the computer.


1. Remove the 4 screws on the bottom case as shown below.




2. Then you can access the M.2 socket and the RTC battery on the daughter board.



3. If you want to access the main board beneath, remove the 4 screws as shown.



4. Then you can access the memory sockets and the connectors on the main board.



## 4.2. Installing M.2 SSD

The computer comes with a M.2 m-key 2280 socket for SSD installation. To install the SSD module:

1. Refer to "[4.1. Access the Inside of the Computer](#)" to locate the M.2 socket for storage installation.
2. Confront the SSD module's edge connector with the M.2 socket. Align the SSD module's key notch at the break on the M.2 socket. By a slanted angle, fully plug the memory module until it cannot be plugged any more.



3. Using the screw coming with the SSD module kit, fix the SSD module in plac




### 4.3. Installing Memory Module

The computer comes with 2 DDR4 SO-DIMM memory sockets for RAM installation. To install the memory module:

1. Refer to "[4.1. Access the Inside of the Computer](#)" to locate the memory module socket on the main board for memory installation.
2. Confront the memory module's edge connector with the memory socket. Align the memory module's key notch at the break on the memory socket. By a slanted angle, fully plug the memory module until it cannot be plugged any more.

Align the memory module's key notch at the SO-DIMM slot connector's break.




3. Press down the memory module until it is auto-locked in place.




## 4.4. Replacing RTC Battery

If your computer is losing its time or date settings, or you are receiving a message about CMOS error, then the RTC battery needs to be replaced. To replace the RTC battery, contact ARBOR Technology to get the new RTC battery and follow the steps below.


1. Refer to "[4.1. Access the Inside of the Computer](#)", locate the RTC battery.
2. Disconnect the existing RTC battery's connector from the system board.



3. Using a non-metallic tool, pry up the RTC battery from the adhesive that secures the battery.



4. With the adhesive side down, place the new RTC battery into position on the system board.
5. Connect the RTC battery cable to the RTC connector on the system board.




### 4.5. Wall Mount the Computer


**Note:** The computer is only suitable for mounting at heights < 2 m.

To mount the computer to a wall or to the rear of a display monitor, you will need a wall mount bracket from ARBOR Technology. The wall mount bracket pack includes:

- 8 x M2.5x4 screws
- 1 x Wall Mount Bracket




The wall mount bracket dimension is shown as below:






To wall mount the equipment, follow the steps below to proceed.

1. Using the provided M2.5x4 screws, fasten the wall mount bracket to the computer as shown below.



2. Using the cutouts of the bracket, mount the assembly to intended wall or location using the provided M2.5x4 screws.



---

This page is intentionally left blank.


# Chapter 5

# BIOS

### 5.1. Main

The AMI BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS RAM of the system stores the Setup utility and configurations. When you turn on the computer, the AMI BIOS is immediately activated. To enter the BIOS SETUP UTILITY, press “Delete” once the power is turned on.

The **Main Setup** screen lists the following information:



Setting	Description
System Language	Choose the system default language.
System Date	Set the system date. Use Tab to switch between Data elements. Note that the ‘Day’ automatically changes when you set the date. ► The date format is: <b>Day:</b> Sun to Sat <b>Month:</b> 1 to 12 <b>Date:</b> 1 to 31 <b>Year:</b> 1998 to 2099


System Time	<p>Set the system time. Use Tab to switch between Time elements.</p> <ul style="list-style-type: none"> <li>▶ The time format is:     <b>Hour:</b> 00 to 23                                    <b>Minute:</b> 00 to 59                                    <b>Second:</b> 00 to 59</li> </ul>
-------------	--

### Key Commands

BIOS Setup Utility is mainly a key-based navigation interface. Please refer to the following key command instructions for navigation process.

Keystroke	Function
◀ ▶	Move to highlight a particular configuration screen from the top menu bar / Move to highlight items on the screen
▼ ▲	Move to highlight previous/next item
Enter	Select and access a setup item/field
Esc	On the Main Menu – Quit the setup and not save changes into CMOS (a message screen will display and ask you to select “OK” or “Cancel” for exiting and discarding changes. Use “←” and “→” to select and press “Enter” to confirm) On the Sub Menu – Exit current page and return to main menu
Page Up / +	Increase the numeric value on a selected setup item / make change
Page Down / -	Decrease the numeric value on a selected setup item / make change
F1	Activate “General Help” screen
F10	Save the changes that have been made in the setup and exit. (a message screen will display and ask you to select “OK” or “Cancel” for exiting and saving changes. Use “←” and “→” to select and press “Enter” to confirm)

## 5.2. Advanced



Setting	Description
CPU Configuration	See section <a href="#">5.2.1. CPU Configuration</a> on page <a href="#">37</a>
ACPI Settings	See section <a href="#">5.2.2. ACPI Settings</a> on page <a href="#">38</a>
USB Configuration	See section <a href="#">5.2.3. USB Configuration</a> on page <a href="#">39</a>
Hardware Monitor	See section <a href="#">5.2.4. Hardware Monitor</a> on page <a href="#">41</a>
S5 RTC Wake Settings	See section <a href="#">5.2.5. S5 RTC Wake Settings</a> on page <a href="#">42</a>
CSM Configuration	See section <a href="#">5.2.6. CSM Configuration</a> on page <a href="#">43</a>
NVMe Configuration	See section <a href="#">5.2.7. NVMe Configuration</a> on page <a href="#">44</a>

### 5.2.1. CPU Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Advanced


CPU Configuration		
Type	Intel(R) Core(TM) i5-7300U CPU @ 2.60GHz	Enabled for windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper-Threading Technology). When Disabled only one thread per enabled core is enabled.
ID	0x806E9	
Speed	2700 MHz	
L1 Data Cache	32 KB x 2	
L1 Code Cache	32 KB x 2	
L2 Cache	256 KB x 2	
L3 Cache	3 MB	
L4 Cache	N/A	
VMX	Supported	
SMX/TXT	Supported	
VMX	[Enabled]	
Active Processor Cores	[All]	
Hyper-Threading	[Enabled]	
Boot performance Mode	[Max Non-Turbo Performance]	
Intel (R) SpeedStep (tm)	[Enabled]	

++: Select Screen  
 |↑: Select Item  
 Enter: Select  
 +/-: Change Opt.  
 F1: General Help  
 F2: Previous Values  
 F9: Optimized Defaults  
 F10: Save and Exit  
 ESC: Exit

Version 2.18.1263. Copyright (C) 2019 American Megatrends, Inc.

Setting	Description
VMX	Enable or disable Intel virtualization technology. ▶ Options: <b>Enabled</b> (default) or <b>Disabled</b>
Active Processor Cores	Number of cores to enable in each processor package. ▶ Options: <b>All</b> (default) and <b>1</b>
Hyper-threading	<b>Enabled</b> (default) for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and <b>Disabled</b> for other OS (OS not optimized or Hyper-Threading Technology). When disabled only one thread per enabled core is enabled.
Boot performance Mode	Set the performance state that the BIOS will set before the OS handoff. ▶ Options: <b>Max Non-Turbo Performance</b> (default), <b>Max Power Saving</b> and <b>Turbo Performance</b>
Intel (R) Speed Step (tm)	<b>Enable</b> (default)/ <b>Disable</b> Intel SpeedStep. Allows more than two frequency ranges to be supported.

### 5.2.2. ACPI Settings



Setting	Description
Enable Hibernation	<b>Enable</b> (default) or <b>Disable</b> System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.



### 5.2.3. USB Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.  
**Advanced**

USB Configuration		Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
USB Module Version	17	
USB Devices:	1 XHCI	
USB Devices:	1 Keyboard	
Legacy USB Support	[Enabled]	→←: Select Screen ↓↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save and Exit ESC: Exit
XHCI Hand-off	[Enabled]	
USB Mass Storage Driver Support	[Enabled]	
Port 60/64 Emulation	Enabled	
USB hardware delays and time-outs:		
USB Transfer time-out	[20 sec]	
Device reset time-out	[20 sec]	
Device power-up delay	[Auto]	

Version 2.18.1263. Copyright (C) 2019 American Megatrends, Inc.

Setting	Description
Legacy USB Support	Sets legacy USB support. ► Options: <b>Enabled</b> (default), <b>Disabled</b> and <b>Auto</b> . <b>AUTO</b> option disables legacy support if no USB devices are connected. <b>Disable</b> option will keep USB devices available only for EFI applications.
XHCI Hand-off	<b>Enable</b> (default) or <b>Disable</b> XHCI Hand-off This is a workaround for Oses without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	<b>Enable</b> (default) or <b>Disable</b> USB Mass Storage Driver Support.
Port 60/64 Emulation	<b>Enable</b> (default) or <b>Disable</b> port 60h/64h emulation support. This should be enabled for the complete USB keyboard legacy support for non-USB aware Oses.

USB hardware delay and time-out	
USB Transfer time-out	<p>Use this item to set the time-out value for control, bulk, and interrupt transfers.</p> <ul style="list-style-type: none"> <li>Options available are: <b>1 sec, 5 sec, 10 sec, 20 sec</b> (default)</li> </ul>
Device reset time-out	<p>Use this item to set USB mass storage device start unit command time-out.</p> <ul style="list-style-type: none"> <li>Options available are: <b>10 sec, 20 sec</b> (default), <b>30 sec, 40 sec</b></li> </ul>
Device power-up delay	<p>Use this item to set maximum time the device will take before it properly reports itself to the host controller.</p> <ul style="list-style-type: none"> <li>Options available are: <ul style="list-style-type: none"> <li><b>Auto</b> (Default): 'Auto' uses default value: for a root port it is 100 ms, for a hub port the delay is taken from hub descriptor.</li> <li><b>Manual</b>: Select <b>Manual</b> you can set value for the following sub-item: '<b>Device Power-up delay in seconds</b>', the delay range in from 1 to 40 seconds, in one second increments.</li> </ul> </li> </ul>

## 5.2.4. Hardware Monitor

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Advanced

PC Health Status


CPU Temperature	: +37°C
Fan1 Speed	: N/A
VCORE	: +0.858 V
VCCDU	: +1.189 V
VIN	: +11.942 V

→: Select Screen  
↓↑: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F9: Optimized Defaults  
F10: Save and Exit  
ESC: Exit

Version 2.18.1263. Copyright (C) 2019 American Megatrends, Inc.


Access this submenu to monitor the hardware status.

5.2.5. S5 RTC Wake Settings




Setting	Description
Wake System from S5	<p><b>Enable</b> or <b>Disable</b> (default) system wake on alarm event.</p> <ul style="list-style-type: none"> <li>Options available are:                             <ul style="list-style-type: none"> <li><b>Disabled</b> (default):                                     <ul style="list-style-type: none"> <li><b>Fixed Time:</b> System will wake on the hr::min::sec specifiedc.</li> <li><b>DynamicTime:</b> If selected, you need to set <b>Wake up minute increase</b> from 1 - 5. System will wake on the current time + increase minute(s).</li> </ul> </li> </ul> </li> </ul>

## 5.2.6. CSM Configuration




Setting	Description
CSM Support	<b>Enable</b> (default) or <b>Disable</b> CSM Support.
Boot option filter	Control the Legacy/UEFI ROMs priority. ▶ Options: <b>UEFI and Legacy</b> (default), <b>Legacy only</b> and <b>UEFI only</b>
Network	Control the execution of UEFI and Legacy PXE OpROM ▶ Options: <b>Do not launch</b> (default) and <b>Legacy</b>
Storage	Control the execution of UEFI and Legacy Storage OpROM ▶ Options: <b>Do not launch</b> and <b>Legacy</b> (default)
Video	Control the execution of UEFI and Legacy Video OpROM ▶ Options: <b>Do not launch</b> and <b>Legacy</b> (default)

### 5.2.7. NVMe Configuration



Access this submenu to view the NVMe controller and driver information.

### 5.3. Chipset



Setting	Description
System Agent (SA) Configuration	
Memory Configuration	Access this submenu to view the memory configuration.
Graphic Configuration	See section <a href="#">5.3.1. Graphics Configuration</a> on page <a href="#">46</a>
PCI-IO Configuration	
SATA And RST Configuration	See section <a href="#">5.3.2 SATA and RST Configuration</a> on page <a href="#">46</a>
LAN Configuration	
PHC LAN Controller	Enables/Disables onboard NIC. ▶ Options: <b>Enabled</b> (default) and <b>Disabled</b>
Wake on LAN Enable	Availabe if PCH LAN Controller is enabled: ▶ Options: <b>Enable</b> (default) / <b>Disable</b> integrated LAN to wake the system.

### 5.3.1. Graphics Configuration

Setting	Description
Internal Graphics	Keep IGFX enabled based on the setup options. ▶ Options: <b>Auto</b> (default), <b>Disabled</b> and <b>Enabled</b>
GTT Size	Select the GTT Size. ▶ Options: <b>4MB</b> , <b>2MB</b> and <b>8MB</b> (default).
Aperture Size	Select the Aperture Size. Note that above 4GB MMIO BIOS assignment is automatically enabled when selecting 2048MB aperture. To use this feature, please disable CSM support. ▶ Options: <b>256MB</b> (default), <b>128MB</b> , <b>512MB</b> , <b>1024MB</b> , <b>2048MB</b> and <b>4096MB</b> .
DVMT Pre-Allocated	Select the DVMT 5.0 Pre-allocated (Fixed) Graphic Memory size used by the Internal Graphic Device. ▶ Options: <b>32M</b> is the default.
DVMT total Gfx Mem	Select the DVMT 5.0 Total Graphic Memory size used by the Internal Graphic Device. ▶ Options: <b>256MB</b> (default), <b>128MB</b> and <b>Max</b> .


### 5.3.2. SATA and RST Configuration

Setting	Description
SATA Controller(s)	<b>Enable</b> (default) or <b>disable</b> SATA Device.
SATA Mode Selection	Determines how SATA controller(s) operate. ▶ Options: <b>AHCI</b> (default) and <b>RAID</b>
SATA Controller Speed	Indicates the maximum speed the SATA controller can support. ▶ Options: <b>Default</b> (default), Gen1, Gen2 and <b>Gen3</b>
Port 1	<b>Enable</b> or <b>disable</b> (default) SATA Port.
SATA Device Type	Identify the SATA port is connected to Solid State Drive or hard Disk Drive. ▶ Options: <b>Hard Disk Drive</b> (default) and <b>Solid State Drive</b>




## 5.4. Security

The **Security** menu sets up the administrator password.




Setting	Description
Administrator Password	<p>To set up an administrator password:</p> <ol style="list-style-type: none"> <li>1. Select <b>Administrator Password</b>. The screen then pops up an <b>Create New Password</b> dialog.</li> <li>2. Enter your desired password that is no less than 3 characters and no more than 20 characters.</li> <li>3. Hit [Enter] key to submit.</li> </ol>

### 5.5. Boot



Setting	Description
Setup Prompt Timeout	Sets how long to wait for the prompt for entering BIOS Setup to show. Set it to <b>65535</b> to wait indefinitely. The default setting is <b>1</b> (sec)
Boot NumLock State	Select the keyboard NumLock state. ► Options: <b>On</b> (default) and <b>Off</b> .
Quiet Boot	<b>Enable</b> (default) or <b>Disable</b> Quiet Boot option.
Boot Option	Sets the system boot order. The options depends on your installation
Hard Drive BBS Priorities	Only available if mSATA or USB storage device is installed. Use this option to set the order of the legacy devices in this group

## 5.6. Save & Exit



Setting	Description
Save Changes and Exit	Exit system setup after saving the changes. ▶ Enter the item and then a dialog box pops up: <b>Save configuration and exit? (Yes/ No)</b>
Discard Changes and Exit	Exit system setup without saving the changes. ▶ Enter the item and then a dialog box pops up: <b>Quit without saving? (Yes/ No)</b>
Restore Defaults	Restore/Load Default values for all the setup options. ▶ Enter the item and then a dialog box pops up: <b>Load Optimized Defaults? (Yes/ No)</b>
Launch EFI Shell from filesystem device	Attempts to launch EFI shell application (Shell.efi) from one of the available filesystem devices.

---

This page is intentionally left blank.