

---

# **iTC-11XX-EXP Series**

**iTC-1150R-EXP / iTC-1170R-EXP**

**Fanless Industrial Panel PC with  
Intel® Elkhart Lake Processor**

## **User's Manual**

**Version 1.1**

---

## Revision History

Version	Date	Description
1.0	2023.05	Initial release
1.1	2023.05	Modify the View Angle in 1.3 Specifications

<b>Revision History .....</b>	<b>ii</b>
<b>Contents .....</b>	<b>i</b>
<b>Preface.....</b>	<b>iii</b>
Copyright Notice .....	iii
Declaration of Conformity .....	iii
CE.....	iii
FCC Class A .....	iii
RoHS .....	iv
SVHC / REACH .....	iv
Important Safety Instructions .....	v
Warning.....	vi
Lithium Battery Replacement.....	vi
Technical Support .....	vi
Warranty.....	vii
<b>Chapter 1 - Introduction.....</b>	<b>1</b>
1.1. The Computer .....	2
1.2. About this Manual .....	2
1.3. Specifications.....	3
1.4. Inside the Package .....	4
<b>Chapter 2 - Getting Started.....</b>	<b>7</b>
2.1. Dimensions .....	8
2.2. Tour the Computer .....	9
2.2.1. Front View.....	9
2.2.2. Bottom View.....	9
2.2.3. Top View .....	10
2.3. I/O Definition .....	11
2.4. Driver Installation Note.....	13
<b>Chapter 3 - Engine of the Computer.....</b>	<b>15</b>
3.1. Board Layout.....	16
3.2. Pin Header .....	18
3.2.1. Pin Header .....	18
<b>Chapter 4 - Installation and Maintenance.....</b>	<b>19</b>
4.1.1 Remove the Rear Cover from the device .....	20
4.1.2. Install Wi-Fi Module .....	21
4.1.3 Install the M.2 SSD Module .....	26
4.1.4. Install SSD or HDD (iTC-1150R-EXP / iTC-1170R-EXP) .....	28
4.1.5. Install PCIe Expansion Cards (iTC-1150R-EXP / iTC-1170R-EXP).....	30
4.1.6. Expansion of Power Backup Solution.....	33

- 4.2. Mount the Computer ..... 35
  - 4.2.1. iTC-1150R-EXP / iTC-1170R-EXP Panel Mounting..... 35
  - 4.2.2. iTC-1150R-EXP / iTC-1170R-EXP VESA Mounting (Optional Accessory)..... 35
- Chapter 5 - BIOS ..... 37**
  - 5.1. Main ..... 40
  - 5.2. Advanced ..... 41
    - 5.2.1. CPU Configuration..... 42
    - 5.2.2. Trusted Computing ..... 43
    - 5.2.3. ACPI Settings..... 44
    - 5.2.4. Super IO Configuration ..... 45
    - 5.2.5. Hardware Monitor ..... 47
    - 5.2.6. S5 RTC Wake Settings ..... 48
    - 5.2.7. PCI Subsystem Setting..... 49
    - 5.2.8. USB Configuration ..... 50
    - 5.2.9. Network Stack Configuration ..... 52
    - 5.2.10. NVME Configuration ..... 53
  - 5.3. Chipset..... 54
    - 5.3.1. **Graphics Configuration ..... 55**
    - 5.3.2. **SATA Configuration ..... 56**
    - 5.3.3. USB Configuration ..... 57
  - 5.4. Security ..... 58
    - 5.4.1. Security Boot ..... 59
  - 5.5. Boot..... 60
  - 5.6. Save & Exit ..... 61

## Copyright Notice

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve the reliability, design and function. It does not represent a commitment on the part of the manufacturer.

Under no circumstances will the manufacturer be liable for any direct, indirect, special, incidental, or consequential damages arising from the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## Declaration of Conformity

### CE

The CE symbol on your product indicates that it is in compliance with the directives of the Union European (EU). A Certificate of Compliance is available by contacting Technical Support.

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from ARBOR. Please contact your local supplier for ordering information.

### Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### FCC Class A

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### RoHS

ARBOR Technology Corp. certifies that all components in its products are in compliance and conform to the European Union's Restriction of Use of Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive 2002/95/EC.

The above mentioned directive was published on 2/13/2003. The main purpose of the directive is to prohibit the use of lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE) in electrical and electronic products. Member states of the EU are to enforce by 7/1/2006.

ARBOR Technology Corp. hereby states that the listed products do not contain unintentional additions of lead, mercury, hex chrome, PBB or PBDB that exceed a maximum concentration value of 0.1% by weight or for cadmium exceed 0.01% by weight, per homogenous material. Homogenous material is defined as a substance or mixture of substances with uniform composition (such as solders, resins, plating, etc.). Lead-free solder is used for all terminations (Sn(96-96.5%), Ag(3.0-3.5%) and Cu(0.5%)).

### SVHC / REACH

To minimize the environmental impact and take more responsibility to the earth we live, Arbor hereby confirms all products comply with the restriction of SVHC (Substances of Very High Concern) in (EC) 1907/2006 (REACH --Registration, Evaluation, Authorization, and Restriction of Chemicals) regulated by the European Union.

All substances listed in SVHC < 0.1 % by weight (1000 ppm)

## Important Safety Instructions

Read these safety instructions carefully

1. Read all cautions and warnings on the equipment.
2. Place this equipment on a reliable surface when installing. Dropping it or letting it fall may cause damage
3. Make sure the correct voltage is connected to the equipment.
4. For pluggable equipment, the socket outlet should be near the equipment and should be easily accessible.
5. Keep this equipment away from humidity.
6. The openings on the enclosure are for air convection and protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
7. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
8. Never pour any liquid into opening. This may cause fire or electrical shock.
9. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
10. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped or damaged.
  - f. The equipment has obvious signs of breakage.
11. Keep this User's Manual for later reference.

## **Warning**

The Panel PC and its components contain very delicately Integrated Circuits (IC). To protect the Panel PC and its components against damage caused by static electricity, you should always follow the precautions below when handling it:

1. Disconnect your Panel PC from the power source when you want to work on the inside.
2. Use a grounded wrist strap when handling computer components.
3. Place components on a grounded antistatic pad or on the bag that came with the Panel PC, whenever components are separated from the system.

## **Lithium Battery Replacement**

Incorrect replacement of the lithium battery may lead to a risk of explosion.

The lithium battery must be replaced with an identical battery or a battery type recommended by the manufacturer.

Do not throw lithium batteries into the trash can. It must be disposed of in accordance with local regulations concerning special waste.

## **Technical Support**

If you have any technical difficulties, please consult the user's manual first at:  
<http://www.arbor.com.tw>

Please do not hesitate to call or e-mail our customer service when you still cannot find out the answer.

<https://www.arbor-technology.com>



## **Warranty**

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster.

Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Vendor will not be liable for any claim made by any other related party.

Vendors disclaim all other warranties, either expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the hardware, the accompanying product's manual(s) and written materials, and any accompanying hardware. This limited warranty gives you specific legal rights.

Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

---

This page is intentionally left blank.

---

# Chapter 1

## Introduction

## 1.1. The Computer

### Product Highlights

(\*Product appearance varies by model.)

- Intel® Celeron® Processor J6413 (1.5M Cache, up to 3.00 GHz)
- 15" 1024 x 768 XGA LCD display
- 17" 1280 x 1024 SXGA LCD display
- Fanless design w/ Aluminum Front bezel
- Flush front panel w/ IP65 waterproof compliant
- Support 2.5GbE LAN and USB 3.2 Gen1 (5Gbps)
- Rich I/O: 6 x COM/ 2 x LAN/ 4 x USB3.2(5Gbps)/ 8-bit DI/O & dual video output: DisplayPort and DVI-D
- Easy-accessible expansion for storage and wireless module
- 9~36V wide-range DC input with reverse protection
- Support PCIe x 1 (half-length) and PCI 32-bit expansion



## 1.2. About this Manual

This manual is meant for the experienced users and integrators with hardware knowledge of personal computers. If you are not sure about the description in this manual, consult your vendor before further handling.

We recommend that you keep one copy of this manual for the quick reference for any necessary maintenance in the future. Thank you for choosing ARBOR products.

### 1.3. Specifications

System	
CPU	Intel® Celeron® J6413 Quad-Core™ Processor 1.80GHz
Memory	1 x 260 pin DDR4 SO-DIMM socket, supporting 3200MHz SDRAM up to 32GB (4GB DDR4 SO-DIMM pre-installed)
LAN Chipset	1 x Intel® 225LM controller 1 x Intel® i210 / i211AT controller
Watchdog Timer	1~255 levels reset
TPM	Support TPM 2.0
Storage	
Device	1 x M.2 M-Key 2242/ 2280 (SATAIII only) 1 x 2.5" SSD/ HDD tray
Audio	
Device	1 x Mic-in / 1 x Line out
Speaker	2 x 1.5W speakers (optional)
LCD Display	
Size/Type	iTC-1150R-EXP: 15" TFT LCD Panel iTC-1170R-EXP: 17" TFT LCD Panel
Max. Resolution	iTC-1150R-EXP: 1024 x 768, XGA iTC-1170R-EXP: 1280 x 1024, SXGA
Max. Colors	iTC-1150R-EXP: 16.2M iTC-1170R-EXP: 16.7M
Luminance	iTC-1150R-EXP: 350 cd/m <sup>2</sup> iTC-1170R-EXP: 350 cd/m <sup>2</sup>
Touch Screen	iTC-1150R-EXP: Flat 5-wire Analog Resistive iTC-1170R-EXP: Flat 5-wire Analog Resistive
View Angle (U/D/R/L)	iTC-1150R-EXP: 88°/88°/88°/88° iTC-1170R-EXP: 60°/80°/80°/80°
Power System	
Power Input	DC 9~36V
Power Consumption	iTC-1150R-EXP: Typical 25W (w/o I/O cards) iTC-1170R-EXP: Typical 40W (w/o I/O cards)
Remote Control	1x3-pin terminal block for remote control and PWR LED output
Qualification	
Certification	CE, FCC Class A

<b>External I/O</b>	
Expansion Bus	1 x Mini PCIe slot (PCIe x1+ USB2.0, Full size) w/ 1 x SIM card slot (for Wireless connection)
	1 x PCIe x1 slot (default, for half-length) or 1 x PCI 32-bit slot (both Riser Cards are included in Standard Accessories)
Serial Ports	2 x DB-9 connectors for RS232/422/485 4 x DB-9 connectors for RS232
USB Ports	4 x Type-A USB 3.2 Gen 1 (5Gbps)
LAN	1 x RJ-45 port for GbE LAN 1 x RJ-45 port for 2.5 GbE LAN
Video Ports	1 x DVI-D connector, supporting Full HD resolution 1 x DisplayPort 1.4 connector, supporting 4K2K resolution
DIO	8 bit Digital I/O
<b>Mechanical</b>	
Mounting Type	Panel mount VESA-75/100 mount (optional)
Chassis	Aluminum front bezel and steel-metal chassis
Dimension (W x H x D)	iTC-1150R-EXP: 367 x 299 x 99 mm iTC-1170R-EXP: 415 x 347 x 100 mm
Weight (Net)	iTC-1150R-EXP: 5.2 kg iTC-1170R-EXP: 6.3 kg
<b>Environmental</b>	
Operating Temp.	-10°C ~ 55°C (14°F ~ 131°F)
Storage Temp.	-20°C ~ 70°C (-4°F ~ 158°F)
Operating Humidity	10 ~ 95% RH @ 55°C (non-condensing)
Vibration	5 ~ 500Hz, 1Grms Random (with SSD)
Shock	Operating 10G, 11ms X,Y,Z axis (with SSD)
<b>OS Support</b>	
Windows®10 (64bit), Windows®11 (64bit)	

## 1.4. Inside the Package

Upon opening the package, carefully inspect the contents. If any of the items is missing or appears damaged, contact your local dealer or distributor. The package should contain the following items:



1 x iTC-1150R-EXP / iTC-1170R-EXP

\*Product appearance varies by model.

### iTC-1150R-EXP / iTC-1170R-EXP Accessory Box

1 x **Accessory Box** that contains the following items:

- User Manual
- 4 x M3\*4L screws (for 2.5" SSD/ HDD tray)
- Panel-mount Clamps w/ screws (clamps and M4\*18L screws)
- 10-pin plug (for D I/O)
- 1 x Rubber O-ring
- 3-pin plug x 2 (one for DC input block; one for Remote Control block)
- 1 x PCIe1 & 1 x PCI Riser Cards

---

This page is intentionally left blank.




---

# Chapter 2


## Getting Started

## 2.1. Dimensions

### iTC-1150R-EXP



### iTC-1170R-EXP



## 2.2. Tour the Computer

Take a look around the computer and find the external controls and connectors.


### 2.2.1. Front View



\*Product appearance varies by model.


### 2.2.2. Bottom View

#### iTC-1150R-EXP/iTC-1170R-EXP



### 2.2.3. Top View

## iTC-1150R-EXP/iTC-1170R-EXP



### iTC-iTC-1150R-EXP / iTC-1170R-EXP

No.	Description
①	Power button
②	2 x RJ-45 GbE port
③	4 x Type-A USB 3.0/2.0 ports
④	1 x DisplayPort 1.4 connector, supporting 4K2K resolution
⑤	1 x DVI-D connector, supporting Full HD resolution
⑥	8 bit Digital I/O
⑦	3-pin terminal block for Power Input
⑧	1 x 2.5" SSD/ HDD tray
⑨	Expansion Card slot
⑩	COM1, COM2, RS-232/422/485 selectable
⑪	1x3-pin terminal block for remote control and PWR LED output
⑫	1 x Mic-in
⑬	1 x Line out
⑭	SMA Antenna Holes for optional WiFi Function

## 2.3. I/O Definition

### ⑥ 8 bit Digital I/O

**Function:** Digital I/O Connector

**Connector Type:**

**Pin Assignment:**

Pin	Desc.	Pin	Desc.
+	DIO_POWER	5	GPIO81
1	GPIO80	6	GPIO83
2	GPIO82	7	GPIO85
3	GPIO84	8	GPIO87
4	GPIO86	-	GND

D/I/O




### ⑦ PWRIN1

**Function:** Power input terminal block

**Connector Type:** 1x3-pin Terminal block

**Pin Assignment:**

Pin	Desc.
1	Power Input +
2	Power Input -
3	Earth Ground




### ⑪ 3-pin terminal block

**Function:** 3-pin terminal block for remote control and PWR LED

**Connector Type:** 1x3-pin Terminal block

**Pin Assignment:**

Pin	Desc.
1	Power button+
2	GND
3	LED+




### ⑩ COM1, COM2 and RS232

**Function:** RS-232/422/485 Selectable Serial Port

**Connector Type:** External 9-pin D-sub male connector

**Pin Assignment:**

	Pin	Desc.	Pin	Desc
<b>RS-232</b>	1	DCD	6	DSR
	2	RXD	7	RTS
	3	TXD	8	CTS
	4	DTR	9	RI
	5	GND		
<b>RS-422</b>	1	COM_422 TX-		
	2	COM_422 TX+		
	3	COM_422 RX+		
	4	COM_422 RX-		
	5	GND		
<b>RS-485</b>	1	COM_485 D-		
	2	COM_485 D+		
	5	GND		



## 2.4. Driver Installation Note

### Windows 10 64-Bit

To install the drivers, please visit our website at **[www.arbor-technology.com](http://www.arbor-technology.com)** and download the driver pack from the product page. If you need login access, please contact your local ARBOR sales representative.

Device	Driver Path
Audio	Audio\0006-64bit_Win7_Win8_Win81_Win10_R279.exe
Ethernet	Ethernet\Wired_driver_26.3_x64.exe
Graphic	Graphic\Installer.exe
Intel_CSE	Intel_CSE\SetupME.exe
Intel_HID Event Filter	Intel_HID Event Filter\Installer\Setup.exe
Intel_Serial IO	Intel_Serial IO\616361_serialIO_driver_Windows10_64bit_ElkhartLake_RelNotes.pdf (Please check page 12 of RelNotes.pdf file to install the driver)
PenMount Touch Driver	PenMount Touch Driver\Setup.exe (Only apply to iTC-1121R / iTC-1150R and iTC-1170R Series)

---

This page is intentionally left blank.




---

# Chapter 3

## Engine of the Computer

### 3.1. Board Layout



## Pin Headers

Label	Description
① JBAT1	CMOS Settings

## Buttons

Label	Description
② SW1	Power Button
③ CN3	Reset Button

## Connectors



Label	Description
① ② ③ ④ CN12, CN11, CN14, CN13	COM Ports
⑤ JPIC1	PIC programming pin header
⑥ CN15	Digital I/O Connector
⑦ CN2	Remote button and LED
⑧ ⑨ CN8, CN9	USB Connector
⑩ CN4	SMBUS Connector
⑪ FAN1	FAN Connector
⑫ JPOWER1	Power Input connector
⑬ JPOWER2	Power Output connector
⑭ SATAPWR	SATA Power Connector
⑮ PCIe1	PCIe Connector
⑯ SATA1	Serial ATA Connector
⑰ ⑱ CN6, CN7	USB Connector
⑲ INV1	LVDS Back light Connector
⑳ TPC1	Resistive Touch Connector
㉑ LVDS1	LVDS Connector
㉒ CN16	AUDIO Connector
㉓ DGP1	Debug Port
㉔ CN5	HDA Connector

## 3.2. Pin Header

### 3.2.1. Pin Header

#### ❶ JBAT1

**Function:** Clears/keeps CMOS  
**Jumper Type:** 2.00 mm pitch 1x2-pin header  
**Setting:**

	Pin	Description
		1 2
<b>Short</b>	Clears CMOS	
		1 2
<b>Open</b>	Keeps CMOS (default)	


---

# Chapter 4


## Installation & Maintenance

### 4.1.1 Remove the Rear Cover from the device

1. Loosen and remove the 6 screws securing the computer's rear and side cover.





2. Dismount the rear cover from the computer. The inside of the computer comes to view.



#### 4.1.2. Install Wi-Fi Module


1. Locate the **Mini PCIe** socket for wireless module. Note the socket has a break among the connector.





2. Connect the antenna to your wireless module. The wireless module comes with two U.FL connectors - one is "1" and the other is "0". Always follow the connections below for best signal reception.

If you are using only one antenna, connect the antenna's MHF end to the connector labeled "1".




Two U.FL connectors, one is "MAIN" (marked 2), the other is "AUX" (marked 1).






- Then plug the Wi-Fi module to the socket's connector by a slanted angle. Fully insert the module, and note that the notch on the wireless module should meet the break of the connector.



The module's key notch should meet the connector's break.


- Press the module down and fix the module in place using the screw.




- Remove a plastic plug from the computer's bottom side to make an antenna hole. Keep the plastic plug for any possible restoration in the future.




6. From the SMA end of the RF antenna, remove the washer and the nut. Save the washer and nut for later use. Note that the SMA connector is in the form of a threaded bolt, with one flat side.



7. Pass the SMA connector through the above mentioned antenna hole. Make sure that you align the connector's flat side with the antenna hole's flat side.



8. Mount the washer first and then the nut to the SMA connector. Make sure the nut is tightened.



Mount the washer and the nut to the SMA connector. Tighten the nut.


9. Have the external antenna(s). Screw and tightly fasten the antenna(s) to the SMA connector.



10. Restore the rear cover to the computer.

### 4.1.3 Install the M.2 SSD Module


1. Locate the **SSD** socket. Note that the socket has a break among the connector. The module's key notch should meet the connector's break.



2. Confront the SSD module's edge connector with the socket's connector. Align the module's key notch with the connector's break and fully plug the module.



3. Press the module down and fix the module in place with one screw.




4. Restore the rear cover to the computer.

#### 4.1.4. Install SSD or HDD (iTC-1150R-EXP / iTC-1170R-EXP)

The iTC-1150R-EXP / iTC-1170R-EXP comes with one 2.5" drive bays for 2.5" HDD or SSD storage device. To install 2.5" HDD or SSD to the computer,


1. Locate the 2.5" drive bays inside the computer. Loosen and remove the screws that locks the door and take the bracket out of computer.



2. Slide the HDD/SSD storage device into the bracket.



3. Fix the storage device in place by fastening the four screws of the bracket.




4. Slide the bracket back to the computer and fasten screws.

#### 4.1.5. Install PCIe Expansion Cards (iTC-1150R-EXP / iTC-1170R-EXP)

The iTC-11xx-EXP series comes with one PCIe expansion slot for external device. To install PCI/ PCIe expansion cards to the computer,

1. Remove the rear cover from the computer as described in [4.1.1 Remove the Rear Cover from the device on page 20](#)
2. Locate the PCIe slot for expansion module. Note the slot has a break among the connector.



3. Loosen and remove the 3 screws securing the computer's rear bracket and remove the bracket out of the computer.






4. Tightly fasten 2 screws to install the expansion card on the bracket.




5. Install the expansion card on main board, then fasten 3 screws.





6. Restore the rear cover to the computer.

#### 4.1.6. Expansion of Power Backup Solution



Please note that if the space of 2.5" SSD or PCI/PCIe IO expansion cards was not occupied, the compartment is available to support an optional Power Backup Solution by ARBOR's SuperCap Technology. If any inquiries for our Power Backup Solution are required, do not hesitate to contact your local dealer or distributor immediately.

## 4.2. Mount the Computer

Install the panel PC to where it works by mounting it to a wall.


### 4.2.1. iTC-1150R-EXP / iTC-1170R-EXP Panel Mounting

1. Have the rubber O-ring included in accessory pack. Put the rubber O-ring on the panel PC.
2. Integrate the panel PC into a correct-sized frame on a wall or other devices.
3. Put the provided clamps into holes around edges of the panel PC then tightly fasten the clamps around edges of the panel PC as the picture below.

Note1: In our case, we took a transparent stand as an example.

Note2: In our case, we took iTC-1170R-EXP for our explanation image.

Panel Mount and Clamps




#### 4.2.2. iTC-1150R-EXP / iTC-1170R-EXP VESA Mounting (Optional Accessory)

1. Have the VESA bracket included in accessory pack. Put the panel PC into VESA bracket.
2. Put the provided VESA-mounting bracket into holes around edges of the panel PC.
3. Tightly fasten the VESA-mounting bracket around edges.

Note1: In our case, we took iTC-1170R-EXP for our explanation image.

VESA Mount



---

This page is intentionally left blank.

---

# Chapter 5

## BIOS

# BIOS

The BIOS Setup utility for the iTC-11XX-EXP series are featured by American Megatrends Inc to configure the system settings stored in the system's BIOS ROM. The BIOS is activated once the computer powers on. When the computer is off, the battery on the main board supplies power to BIOS RAM.

To enter the BIOS Setup utility, keep hitting the "Delete" key upon powering on the computer.



Menu	Description
Main	See <a href="#">5.1. Main</a> on page <a href="#">40</a>
Advanced	See <a href="#">5.2. Advanced</a> on page <a href="#">41</a>
Chipset	See <a href="#">5.3. Chipset</a> on page <a href="#">109</a>
Boot	See <a href="#">5.4. Security</a> on page <a href="#">109</a>
Security	See <a href="#">5.5. Boot</a> on page <a href="#">109</a>
Save & Exit	See <a href="#">5.6. Save &amp; Exit</a> on page <a href="#">109</a>



## Key Commands

The BIOS Setup utility relies on a keyboard to receive user's instructions. Hit the following keys to navigate within the utility and use the utility.


Keystroke	Function
← →	Moves left/right between the top menus.
↓ ↑	Moves up/down between highlight items.
<b>Enter</b>	Selects an highlighted item/field.
<b>Esc</b>	<ul style="list-style-type: none"> <li>▶ On the top menus: Use <b>Esc</b> to quit the utility without saving changes to CMOS. (The screen will prompt a message asking you to select <b>OK</b> or <b>Cancel</b> to exit discarding changes.</li> <li>▶ On the submenus: Use <b>Esc</b> to quit current screen and return to the top menu.</li> </ul>
<b>Page Up / +</b>	Increases current value to the next higher value or switches between available options.
<b>Page Down / -</b>	Decreases current value to the next lower value or switches between available options.
<b>F1</b>	Opens the <b>Help</b> of the BIOS Setup utility.
<b>F2</b>	Set the values to previous values.
<b>F9</b>	Restores all settings to defaults. ▶ This is a command to launch an action from the BIOS Setup utility.
<b>F10</b>	Exits the utility saving the changes that have been made. (The screen then prompts a message asking you to select <b>OK</b> or <b>Cancel</b> to exit saving changes.)

**Note:** Pay attention to the "WARNING" that shows at the left pane onscreen when making any change to the BIOS settings.

This BIOS Setup utility is updated from time to time to improve system performance and hence the screenshots hereinafter may not fully comply with what you actually have onscreen.


## 5.1. Main

The **Main** menu features the settings of **System Date** and **System Time** and displays some BIOS info.




Setting	Description
<b>BIOS Name</b>	Delivers the model name of the computer.
<b>BIOS Version</b>	Delivers the computer's BIOS version.
<b>Build Date and Time</b>	Delivers the date and time when the BIOS Setup utility was made/ updated.
<b>Access Level</b>	Delivers the level that the BIOS is being accessed at the moment.
<b>ME FW Version</b>	Delivers the ME version.
<b>System Date</b>	Sets system date.
<b>System Time</b>	Sets system time.

## 5.2. Advanced



Setting	Description
<b>CPU Configuration</b>	See <a href="#">5.2.1. CPU Configuration</a> on page <a href="#">42</a>
<b>Trusted Computing</b>	See <a href="#">5.2.2. Trusted Computing</a> on page <a href="#">43</a>
<b>ACPI Settings</b>	See <a href="#">5.2.3. ACPI Settings</a> on page <a href="#">44</a>
<b>Super IO Configuration</b>	See <a href="#">5.2.4. Super IO Configuration</a> on page <a href="#">45</a>
<b>Hardware Monitor</b>	See <a href="#">5.2.5. Hardware Monitor</a> on page <a href="#">47</a>
<b>S5 RTC Wake Settings</b>	See <a href="#">5.2.6. S5 RTC Wake Settings</a> on page <a href="#">48</a>
<b>PCI Subsystem Settings</b>	See <a href="#">5.2.7. PCI Subsystem Setting</a> on page <a href="#">49</a>
<b>USB Configuration</b>	See <a href="#">5.2.8. USB Configuration</a> on page <a href="#">50</a>
<b>Network Stack Configuration</b>	See <a href="#">5.2.9. Network Stack Configuration</a> on page <a href="#">52</a>
<b>NVMe Configuration</b>	See <a href="#">5.2.10. NVME Configuration</a> on page <a href="#">53</a>

### 5.2.1. CPU Configuration




Setting	Description
<b>Active Processor Cores</b>	Numbers of cores to enable in each processor package
<b>Intel Virtualization Technology</b>	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology ► Options: <b>Enabled</b> (default) or <b>Disabled</b>
<b>Intel SpeedStep</b>	Allows more than two frequency ranges to be supported <b>Enable</b> (default) / <b>Disable</b> Intel SpeedStep
<b>Turbo Mode</b>	Only available when Intel Speed Step is <b>Enabled</b> . <b>Enable</b> (default) / <b>Disable</b> Turbo Mode
<b>CPU C States</b>	<b>Enable</b> / <b>Disable</b> (default) CPU C States

## 5.2.2. Trusted Computing




Setting	Description
<b>Security Device Support</b>	<b>Enable</b> (default) or <b>Disable</b> BIOS support for security device.
<b>Pending operation</b>	Schedule an Operation for the security Device. Your computer will reboot during restart in order to change State of Security Device. ▶ Options: <b>None</b> (default) and <b>TPM Clear</b>

### 5.2.3. ACPI Settings



Setting	Description
<b>Enable Hibernation</b>	<b>Enables</b> (default) or <b>Disables</b> System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

## 5.2.4. Super IO Configuration




Setting	Description
Serial Port	Enable (default) or Disable Serial Port (COM).

<p><b>Change Settings</b></p>	<p>Select an optimal setting for Super IO device.</p> <ul style="list-style-type: none"> <li>▶ Options for Serial Port 1:            Serial Port: <b>[Enabled]</b>(default); <b>[Disabled]</b>;  <b>IO=3E8h; IRQ=4</b> (default)            Mode Select: <b>RS-232; RS-422; RS485; RS-485 Termination Resistor</b></li> <li>Options for Serial Port 2:            Serial Port: <b>[Enabled]</b>(default); <b>[Disabled]</b>;  <b>IO=2F8h; IRQ=3</b> (default)            Mode Select: <b>RS-232; RS-422; RS485; RS-485 Termination Resistor</b></li> <li>Options for Serial Port 3:            Serial Port: <b>[Enabled]</b>(default); <b>[Disabled]</b>;  <b>IO=3E8h; IRQ=5</b> (default)</li> <li>Options for Serial Port 4:            Serial Port: <b>[Enabled]</b>(default); <b>[Disabled]</b>;  <b>IO=2E8h; IRQ=6</b> (default)</li> <li>Options for Serial Port 5:            Serial Port: <b>[Enabled]</b>(default); <b>[Disabled]</b>;  <b>IO=2F0h; IRQ=7</b> (default)</li> <li>Options for Serial Port 6:            Serial Port: <b>[Enabled]</b>(default); <b>[Disabled]</b>;  <b>IO=2E0h; IRQ=10</b> (default)</li> </ul>
-------------------------------	---



## 5.2.5. Hardware Monitor




Select this submenu to view the main board's hardware status. Select it to run a report of various info as depicted below:

### 5.2.6. S5 RTC Wake Settings




Setting	Description
<b>Wake System from S5</b>	<p><b>Enable or Disable</b> (default) system wake on alarm event.</p> <ul style="list-style-type: none"> <li>▶ Options available are:                             <ul style="list-style-type: none"> <li><b>Disabled</b> (default):</li> <li><b>Fixed Time:</b> System will wake on the hr::min::sec specifiedc.</li> <li><b>DynamicTime:</b> If selected, you need to set <b>Wake up minute increase</b> from 1 - 5. System will wake on the current time + increase minute(s).</li> </ul> </li> </ul>

## 5.2.7. PCI Subsystem Setting



Setting	Description
<b>PCI Latency Timer</b>	Value to be programmed into PCI Latency Timer Register. ► <b>Options: 32 (default), 64, 96, 128, 160, 192, 224 and 248 PCI Bus Clocks.</b>
<b>PCI-X Latency Timer</b>	Value to be programmed into PCI-X Latency Timer Register. ► <b>Options: 32, 64 (default), 96, 128, 160, 192, 224 and 248 PCI Bus Clocks.</b>
<b>Above 4G Decoding</b>	<b>Enable/Disable (default)</b> 64bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64 bit PCI Decoding).


### 5.2.8. USB Configuration



Setting	Description
<b>Legacy USB Support</b>	Enables/disables legacy USB support. <ul style="list-style-type: none"> <li>▶ Options available are <b>Enabled</b> (default), <b>Disabled</b> and <b>Auto</b>.</li> <li>▶ Select <b>Auto</b> to disable legacy support if no USB device are connected.</li> <li>▶ Select <b>Disabled</b> to keep USB devices available only for EFI applications.</li> </ul>
<b>XHCI Hand-off</b>	This is a workaround for OSeS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver. <ul style="list-style-type: none"> <li>▶ The optional settings are: <b>Enabled</b> (default) / <b>Disabled</b>.</li> </ul>
<b>USB Mass Storage Driver Support</b>	Enables/disables USB Mass Storage Driver Support. <ul style="list-style-type: none"> <li>▶ The optional settings are: <b>Disabled</b> / <b>Enabled</b> (default).</li> </ul>
<b>USB hardware delay and time-out</b>	
<b>USB Transfer time-out</b>	Use this item to set the time-out value for control, bulk, and interrupt transfers. <ul style="list-style-type: none"> <li>▶ Options: <b>1 sec</b>, <b>5 sec</b>, <b>10 sec</b>, <b>20 sec</b> (default).</li> </ul>


<b>Device reset time-out</b>	Use this item to set USB mass storage device start unit command time-out. ▶ Options available are: <b>10 sec, 20 sec (default), 30 sec, 40 sec</b>
<b>Device power-up delay</b>	Use this item to set maximum time the device will take before it properly reports itself to the host controller. 'Auto' uses default value: for a root port it is 100 ms, for a hub port the delay is taken from hub descriptor. ▶ Options available are: <b>Auto:</b> Default <b>Manual:</b> Select <b>Manual</b> you can set value for the following sub-item: 'Device Power-up delay in seconds', the delay range in from 1 to 40 seconds, in one second increments.

### 5.2.9. Network Stack Configuration



Setting	Description
Network Stack	Enable or Disable (default) UEFI network stack.

## 5.2.10. NVMe Configuration



Access this submenu to view the NVMe controller and driver information.

### 5.3. Chipset




The features settings are:

Setting	Description
<b>System Agent (SA) Configuration</b>	
<b>Memory Configuration</b>	Access this submenu to view the memory configuration.
<b>Graphics Configuration</b>	See <a href="#">5.3.1. Graphics Configuration</a> on page <a href="#">55</a>
<b>VT-d</b>	<b>Enable</b> (default) or <b>Disable</b> VT-d function
<b>Above 4GB MMIO BIOS assignment</b>	<b>Enable</b> or <b>Disable</b> (default) Above 4GB MMIO BIOS assignment. This is enabled automatically when aperture size is set to 2048MB.
<b>PCH-IO Configuration</b>	
<b>SATA Configuration</b>	See <a href="#">5.3.2. SATA Configuration</a> on page <a href="#">56</a>
<b>USB Configuration</b>	See <a href="#">5.3.3. USB Configuration</a> on page <a href="#">57</a>
<b>State After G3</b>	Specify what state to go to when power is re-applied after a power failure (G3 state). ▶ Options available are <b>Power On</b> (default) and <b>Power Off</b>




### 5.3.1. Graphics Configuration




Setting	Description
<b>GTT Size</b>	Select the GTT Size. ▶ Options: <b>4MB, 2MB</b> and <b>8MB</b> (default).
<b>Aperture Size</b>	Select the Aperture Size. Note that above 4GB MMIO BIOS assignment is automatically enabled when selecting 2048MB aperture. To use this feature, please disable CSM support. ▶ Options: <b>128MB, 256MB</b> (default), <b>512MB, 1024MB</b> and <b>2048MB</b>
<b>DVMT Pre-Allocated</b>	Select the DVMT 5.0 Pre-allocated (Fixed) Graphic Memory size used by the Internal Graphic Device. ▶ 60M is the default.
<b>DVMT Total Gfx Mem</b>	Select the DVMT 5.0 Total Graphic Memory size used by the Internal Graphic Device. ▶ Options: <b>128M, 256M</b> (default) and <b>Max</b> .

### 5.3.2. SATA Configuration




Setting	Description
<b>SATA Controller(s)</b>	<b>Enables</b> (default) / <b>Disables</b> SATA device(s).
<b>Serial ATA Port 0~1</b>	SATA device information. <b>Enables</b> (default) / <b>Disables</b> the SATA port. *Available SATA ports depend on your model.

### 5.3.3. USB Configuration



Setting	Description
<b>XHCI Compliance Mode</b>	<b>Enable / Disable</b> (default) Compliance mode. Options to disable Compliance Mode. Default is <b>FALSE</b> (default) to not disable Compliance Mode. Set <b>TRUE</b> to disable Compliance Mode.
<b>xDCI Support</b>	<b>Enable / Disable</b> (default) xDCI (USB OTG Device).

## 5.4. Security




Setting	Description
<b>Administrator Password</b>	To set up an administrator password: <ol style="list-style-type: none"> <li>1. Select <b>Administrator Password</b>.</li> <li>2. An <b>Create New Password</b> dialog then pops up onscreen.</li> <li>3. Enter your desired password that is no less than 3 characters and no more than 20 characters.</li> <li>4. Hit [Enter] key to submit.</li> </ol>
<b>Security Boot</b>	See <a href="#">5.4.1 Security Boot on page &lt;?&gt;</a> .

## 5.4.1. Security Boot




Setting	Description
<b>Secure Boot</b>	<b>Enable/Disable</b> (default) secure boot.
<b>Secure Boot Mode</b>	Allow users to set the secure boot selector. <b>Standard/Custom</b> (default) mode.
<b>Restore Factory Keys</b>	Force system to restore default secure boot key database.
<b>Reset to Setup Mode</b>	Delete all secure boot key databases.
<b>Key Management</b>	Allow users to modify secure variables and set key management page.

## 5.5. Boot



Setting	Description
<b>Setup Prompt Timeout</b>	Set how long to wait for the prompt to show for entering BIOS Setup. <ul style="list-style-type: none"> <li>▶ The default setting is <b>1</b> (sec).</li> <li>▶ Set it to <b>65535</b> to wait indefinitely.</li> </ul>
<b>Bootup NumLock State</b>	Sets whether to enable or disable the keyboard's NumLock state when the system starts up. <ul style="list-style-type: none"> <li>▶ Options available are <b>On</b> (default) and <b>Off</b>.</li> </ul>
<b>Quiet Boot</b>	Sets whether to display the POST (Power-on Self Tests) messages or the system manufacturer's full screen logo during booting. <ul style="list-style-type: none"> <li>▶ Select <b>Disabled</b> to display the normal POST message, which is the default.</li> </ul>
<b>Boot Option Priority</b>	Set the system boot priorities.

## 5.6. Save & Exit



The features settings are:

Setting	Description
<b>Save Changes and Reset</b>	Saves the changes and quits the BIOS Setup utility.
<b>Discard Changes and Exit</b>	Quits the BIOS Setup utility without saving the change(s).
<b>Restore Defaults</b>	Restores all settings to defaults. ▶ This is a command to launch an action from the BIOS Setup utility.
<b>Boot Override</b>	<b>Boot Override</b> presents a list in context with the boot devices in the system. ▶ <b>P0</b> : Select the device to boot up the system regardless of the currently configured boot priority. ▶ <b>Launch EFI Shell from filesystem device</b> : Attempts to launch EFI Shell Application (Shell.efi) from one of the available filesystem devices.